



Illuminated
selector switch
2 positions

Illuminated
button
spring-return

Illuminated
button
spring-return

Illuminated
button
spring-return

Indicator light

Indicator light

	Contacts	Diagram
Device 1	1NO	A1 — A4 A2 — A3 LED
Device 2	1NO	A1 — A5 A6 — A3 LED
Device 3	1NO	A1 — A7 A12 — A3 LED
Device 4	1NO	B1 — B4 B2 — B3 LED
Device 5	/	B6 — B3 LED
Device 6	/	B12 — B3 LED

